

## Tilt Sensor

### Features

- Alarm for anything that tilts.
- Useful for hatches, roll-up doors and even moveable assets.
- Cover tamper.
- Strong, reliable RF signal.
- 10-15 year battery life on CR123A battery.
- Low Battery indication.

### Enroll

- Place the JAQX Smart Hub into wireless enrollment mode by pressing the external red button for 3 seconds until hub beeps.
- Send an enrollment signal from the sensor by removing the battery tab OR removing the cover to trip tamper.
- Confirm that the sensor has been properly enrolled by checking for new zone on your JAQX App or in your customer portal.
- Once the sensor has been enrolled on your system, turn off sensor enrollment by pressing the external button on the JAQX smart hub for 3 seconds or until hub beeps.
- Call JAQX customer support to rename your sensor.

**Install** by mounting tilt sensor straight up with battery at bottom, tamper switch at top. Mounting upside down will cause over-sensitivity and false alarms. Mount with included 3M VHB tape or #4 or #6 screws.

### Operation:

- Alarm: When tilted more than 45 degrees
- Tamper: When cover is opened

### Internal Picture

Shown in straight up, non-alarm mounting position.

